



Attach this side of box with
 4 #6 x $1 \frac{1}{4}$ Flat head screws